User's Manual


Safety Instructions

- 1. Make sure your battery has enough voltage for the controller to recognize the battery type before first installation.
- 2. The battery cable should be as short as possible to minimize loss.
- 3. The regulator is suitable for lead acid batteries (Flood, AGM,
- GEL)and lithium ions (note the use of please controller is arranged for the right type of battery) it is not suited for nickel metal hydride, or other batteries.
- 4. The charge regulator is only suitable for regulating solar modules never connect another charging source to the charge regulator.
- 5. The controller will be hot when it is working, Please install the controller on a smooth, well ventilated surface.

Product Features

- 1. Build-in industrial micro controller.
- 2. Big Icd display, all adjustable parameter.
- 3. Fully 3-stage pwm charge management.
- 4. Build-in short-circuit protection, open-circuit protection. reverse protection, over-load protection.
- 5. Dual mosfet reverse current protection, low heat production.

LCD Display/Key




menu:switch between different display, or to enter/exit setting by long press.

up:press to increase value.

down:press to decrease value.

- 1. Connect the battery to the charge regulator-plus and minus. 2. Connect the photovoltaic module to the regulator-plus and minus.
- 3. Connect the consumer to the charge regulator-plus and minus.



	d discharge stop
Attn:1.Press the [down] button to on/off load r	nanully at main display.
[24H]Load output 24 hours	

[down]

to enter setting,

and using [up]

Idownl to set the parameter, long

press menu

again to exit.

long press

Obattery type

@ discharge reconnect

[1-23H]Load on after sunset and closed after, setting hours [0H]Dusk to dawn

Trouble Shooting								
Situation	Probable Cause	Solution						
Charge icon not on when sunny	Solar panel opened or reversed	Reconnect						
Load icon off	Mode setting wrong	Set again						
	Battery low	Recharge						
Load icon slow flashing	Over load	Reduce load watt						
Load icon fast flashing	Short circuit protection	Auto reconnect						
Power off	Battery too low/ Reverse	Check battery/ Connection						

flashing	g protection					Auto reconnect			
Power of	Battery too low			/	Check battery/ Connection				
	Tech	nnic	al	Para	me	ete	r		
Model		10	24			2024			
System Voltage	12V/24V AUTO								
Charge Current	10A			20A					
Discharge Current	10A				20A				
Max Solar Input	<50V								
Battery Type	b01 Sealed		b02	b02 GEL			b03 Flood		
Equailzation	1-	4.4V		14.	14.2V			14.6V	
Float Charge	13.7V (defaul, adjustable)								
Discharge Stop	10.7V (defaul,adjustable)								
Discharge Reconnect	12.6V (defaul,adjustable)								
Battery Type	b0 Iron lit 4 Stra	hium	Iror 5 S	b05 h lithium Strands	thium lithium			b07 lithium ion 4 Strands	
Constant Charging Vo l tage		3.6V*4/*5			4.2V*3/*4				
Recovery Charge Voltage	3.4V*4/*5			4.0V*3/*4					
Low Voltage Protection	2.6V*4/*5			3.1V*3/*4					
Low Voltage Recovery	2.9V*4/*5			3.7V*3/*4					
	b04~	b07 Pa	aram	eters can	not	be se	et		
USB Output	5V/2A								
Self-consume	<10mA								
Operating Temperature	-35~+60°C								
Size/Weight	133*70*34mm/154g								

Product specifications are subject to charge without prior notice.